



LE1462_SHB145XX

		Spare part number	Colours available
1	Glass lid (Smoked black)	SSPA0220	.BK
	Glass lid (Solid black)	SSPA0221	.SBK
2	Hinge	SSPA0009	
3	Shut-off assy	SSPA0607	
4	Pan support (Chrome plated)	SSPA0976	
	Pan support (Enameled black)	SSPA0977	
5	Pan support clip 4x	SSPA0041	
	Pan support clip 50x	SSPA0042	
6	Burner assy large		
	Production date: < 10-06-12 (E161N...)	SSPA0123	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0813	
7	Burner assy medium		
	Production date: < 10-06-12 (E161N...)	SSPA0114	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0812	
8	Bezel	SSPA0073	
9a	Gas tap burner large 1x		
	Production date: < 10-06-12 (E161N...)	SSPA0472	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0470	
	Production date: ≥ 02-10-17 (E275U...)	SSPA0474	
9b	Gas tap burner medium 1x		
	Production date: < 10-06-12 (E161N...)	SSPA0432	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0430	
	Production date: ≥ 02-10-17 (E275U...)	SSPA0433	
10	Knobs	<i>Refer to page 3</i>	
11	Spark generator	SSPA0303	
12	Thermocouple		
	Production date: < 10-06-12 (E161N...)	SSPA0150	
	<i>With shutoff</i>	N/A	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0164	
	<i>With shutoff</i>	SSPA0607	
13	Electrode		
	Production date: < 10-06-12 (E161N...)	SSPA0312	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0322	

Control knobs

Control knob sets



Spare part number	SSPA0912	SSPA0914
Colours available	Satin (.SA)	Matt Nickel (.MNK) Black (.BK)
Set quantity	3	3